



MANTA

Selfie Wireless Monopod

MA421



Instrukcja obsługi
User's Manual

Wireless Mobile Phone Monopod

Przeczytaj wszystkie instrukcje przed użyciem i zachować te informacje do wykorzystania w przyszłości.

Zestaw:

- 1x Wireless mobile phone monopod
- 1x Uchwyt na telefon,
- 1x USB przewód

Użytkowanie

- Przesuń przełącznik zasilania w pozycji ON , niebieska dioda zacznie pulsować.
- Włącz funkcję Bluetooth w telefonie komórkowym, aby wyszukać urządzenie, a następnie połącz się z monopodem
- Włącz w telefonie tryb aparatu/kamery.
- Włóż telefon do zacisków monopoda. Upewnij się, że zaciski są zamontowane prawidłowo.
- Przykręć uchwyt telefonu komórkowego do śruby znajdującej się na górze uchwytu statywu.
- Rozłóż Monopod do poziomu jaki potrzebujesz. Nie należy przekraczać maksymalnej długości rozłożenia monopodu (max 1 metr).
- Aby wykonać zdjęcie , wciśnij przycisk z napisem PRESS na ręczce monopodu.
- Aby włączyć Monopod, przesuń przełącznik zasilania do pozycji OFF.



Ładowanie

- Podłącz złącze USB do ładowarki USB (5V) lub do portu USB w komputerze.
- Podczas procesu ładowania dioda sygnalizacyjna świecić się będzie na czerwono, gdy urządzenie jest w pełni naładowane czerwone światło zgaśnie.
- Nie przekraczać czasu ładowania (1 godzina)
- Nie należy pozostawiać urządzenia bez nadzoru podczas ładowania.

Konserwacja i bezpieczeństwo

- Czyszczenie:, wytrzeć urządzenie miękką (umiarkowanie wilgotną) szmatką.
- Nie należy używać agresywnych środków czyszczących do czyszczenia urządzenia.
- Nie zanurzać urządzenia w wodzie lub innej cieczy.
- Trzymaj urządzenie z dala od źródeł ciepła lub materiałów łatwopalnych.
- Urządzenie nie jest przeznaczone do użytku przez osoby (w tym dzieci) o ograniczonej zdolności fizycznej, czuciowej lub psychicznej, lub braku doświadczenia i wiedzy, chyba że będą one nadzorowane lub zostaną poinstruowane na temat korzystania z tego urządzenia przez osobę odpowiedzialną za ich bezpieczeństwo.
- Recykling produkt do utylizacji zgodnie z lokalnymi przepisami.

Uwaga:

Obsługiwane systemy: \geq IOS 6.1, \geq Android 3.7. Ponieważ Android jest systemem Open Source, niektóre telefony komórkowe nie mają funkcji sterowania tele do robienia zdjęć.

Wireless Mobile Phone Monopod

Read all instructions carefully before use and retain this information for future reference.

Features

1x Wireless mobile phone monopod, 1x Phone clamp, 1x USB Cable

Start up

- Slide the wireless mobile phone monopod power switch to 'ON' position, the blue indicator light will start to flash.
- Turn your mobile phone Bluetooth on to search for the device, then the wireless mobile phone monopod will be found by your phone, click to pair it up.
- Enter your mobile phone camera mode 'ON'.
- Insert your mobile phone into the monopod clamps. Ensure the clamps are fitted correctly.
- Screw the mobile phone clamp to the screw provided on the top of the monopod handle.
- Adjust the monopod handle to the level you require. Do not exceed the maximum length of monopod extension (1 Metre).
- To take a picture, operate button marked 'PRESS' on the monopod handle.
- To turn the monopod off, slide the power switch to the 'OFF' position.



To Charge the device

- Attach the USB connector to the monopod input port and then attach the USB connector to a USB portal on your mobile phone.
- When the wireless mobile phone monopod is charging the red light will illuminate, when the device is fully charged the red light will turn off.
- Do not exceed the charging time (1 Hour)
- Do not leave device unattended while it is charging.

Care / Maintenance and Safety

- To clean, wipe the device with a soft (moderately damp) cloth.
- Do not use abrasive cleaning agents to clean the device.
- Do not immerse the wireless mobile phone monopod in water or any other liquid.
- Keep device away from heat source or flammable materials.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Please recycle the product for disposal in accordance with local regulations.

Notes:

Support System: \geq IOS 6.1, Android 3.7. Since Android is Open Source S ystem some mobile phones or bar phones don't have tele control function for taking photos.



CUSTOMER SERVICE

tel: +48 22 332 34 63 or e-mail: serwis@manta.com.pl

FROM MONDAY TO FRIDAY, IN HOURS: 9.00-17.00

The manufacturer reserves the right to introduce changes