

# Bomber

## Game Pad USB MM802



### Manual

#### Product features

1. The directional pad represents UP, DOWN, LEFT, RIGHT and 4 diagonals.
2. 8 Buttons are default fire buttons all are digital in nature.
3. AUTOFIRE switch: Turbo will provide rapid fire shots and movements for the corresponding Action buttons. All Action buttons can be set to auto-fire.

#### Installation

1. Plug the pad connector into the USB port
2. Windows 98 will automatically select correct driver to set up pad. Just follow the on-screen instructions to operate. Once you have completed setup, you must activate and calibrate the pad. Restart your computer.
3. Select SETUP.EXE and follow the steps in order to setup the driver
4. Me/2000/XP only simple plug and play operation

#### Calibration

1. Select Settings/Control Panel from the Start menu. Double-click the Game Controllers in Windows system.
2. Select the corresponding device (if it show OK status)
3. Choose Calibrate button. Follow the on-screen directions for calibrate your pad. Be sure to press the action buttons as prompted and not the Next icon. Click Finish when the calibration process is completed
4. Choose Test to be sure that your controller is correctly calibrated and press OK to exit the test area

### Instrukcja obsługi

#### Cechy produktu

1. Pad kierunkowy umożliwiający ruch: w górę, w dół, a lewo, w prawo i po czterech przekątnych.
2. 8 cyfrowych przycisków „fire”
3. Przełącznik AUTOFIRE umożliwiający podpisanie pod klawisze funkcji ciągłego strzelania lub ruchu. Do każdego przycisku można przypisać funkcję „auto-fire”

#### Instalacja

1. Podłącz wtyczkę pada do portu USB
2. System Windows 98 sam automatycznie wybierze sterowniki skonfigurować urządzenie. Po prostu postępuj wg instrukcji wyświetlających się na ekranie..
3. W Windows Me/2000/XP po przyłączeniu pada system sam go wykryje i oprogramuje na zasadzie „plug and play”

#### Kalibracja

1. Z menu „Start” wybierz „Panel sterowania” i kliknij dwukrotnie ikonę „Kontrolery gier”
2. Wybierz podłączone urządzenie, którego „Stan” wyświetla „OK.”
3. Teraz kliknij „Właściwości” i przejdź do zakładki „Ustawienia”, „Kalibruj” i skonfiguruj urządzenie, postępując wg pokazujących się na ekranie instrukcji. Upewnij się, że zgodnie z poleceniami wciskasz przyciski, a nie klawisz „Dalej”. Wciskając „Zakończ” zatwierdź proces kalibracji.
4. W zakładce „Testuj” sprawdź czy pad został prawidłowo skalibrowany. Wciskając „OK” opuść okno „Kontrolery gier”