





# INSTRUKCJA OBSŁUGI USERS MANUAL

## MM95



### AC POWER CABLE

#### Note:

For Europe: 230V/50Hz  
For USA & Canada: 120V/60Hz  
For Japan: 100V, 50/60Hz  
For Australia: 240V/50Hz

Podłącz kabel zasilania do odpowiedniego źródła prądu. Kształt wtyczki może się różnić od tego z obrazka.



### AUDIO CABLE

### PODŁĄCZENIE

1. Włóż wtyczkę 3,5mm (Stereo Jack) do gniazda słuchawek lub gniazda wyjściowego źródła dźwięku (np. karty dźwiękowej).
2. Podłącz wtyczkę głośników do kontaktu z prądem. Wyjmij wtyczkę z gniazda, jeśli nie używasz głośników.

### OBSŁUGA GŁOŚNIKÓW

1. Wciśnij przycisk POWER, by włączyć głośniki. Zapali się wówczas dioda
2. Włącz źródło dźwięku.
3. Wybierz pokrętką VOLUME pożądaną głośność.
4. By wyłączyć głośniki wciśnij ponownie POWER.

### GETTING STARTED

1. Plug in stereo Jack 3,5 mm to headphones slot or audio out slot of sound source, eq. PC sound card.
2. Plug in power cord to AC slot. Remove the plug from slot when speakers are unused for long period of time.

### HOW TO USE

1. Press POWER button to power up the speakers. Power LED on.
2. Power up sound source.
3. Specify the volume with VOLUME control.
4. Power off the speakers with POWER button.