



Jak zainstalować baterie?

Naciśnij i wypchnij przykrywkę baterii (rys. 1)
Włóż dwie baterie AAA na miejsce uważnie sprawdzając bieguny (rys. 2)
Zamknij myszkę




Jak zainstalować Mini Wireless Optical Mouse?

Wyłącz komputer
Podłącz odbiornik do portu USB (rys. 3)
Włącz komputer
Naciśnij przycisk „Reset” na odbiorniku (rys. 4)
Naciśnij gumowy przycisk na myszce (rys. 5)
Po wykonaniu tych czynności myszka powinna działać



Funkcja: włącz/wyłącz

Gdy myszka nie jest używana, możesz ją wyłączyć przyciskiem „Off” (rys. 6)
Zawsze po wyłączeniu myszki musisz ją ponownie zainstalować




Uwaga!

Zanim podłączysz myszkę do portu USB, sprawdź czy Twój komputer może obsługiwać myszy USB.
Starsze komputery mogą jej nie rozpoznać. Sprawdź to w instrukcji do komputera.
Nie używaj myszki optycznej na powierzchniach błyszczących
Jeśli instalujesz myszkę w systemie Windows 98, upewnij się, że posiadasz płytę instalacyjną Win 98.
Jeśli używasz w jednym pomieszczeniu wielu takich myszek zachowaj między odbiornikami odstęp minimum 1,5m aby zapobiec interferencjom.

How to install batteries?


Press and push battery cap (pic. 1)
Place two AAA batteries in the battery case (pic. 2)
Put back the battery cap



How to start set up Mini Wireless Optical Mouse?


Power off your PC
Connect USB receiver to the USB port on PC (pic. 3)
Power on your PC

Step 1 Press reset button (pic. 4)
Step 2 Press the Rubber Button (pic. 5)
Step 3 Enjoy Your Mini Wireless Optical Mouse



Power on-off function

When mouse is not in use, you can turn the battery switch off (pic. 6)
Please make sure to setup for linkage AGAIN for next time use
(please refer to Section 2)



Notice!

To set the USB Mouse port
Before connecting the mouse to a USB port on the computer, please make sure that your computer supports USB mouse. Some older computer do not fully support for USB Mouse. Please refer to the computer manual for additional information
Do NOT use optical mouse on metal surface or reflecting surfaces
If your operating system is Windows 98, please make sure to install Windows 98 CD before using USB input device
Keep a distance of more than 1.5 m to avoid interference if there are other RF devices in use.